

Smoker Cease Fire™ Station

GREAT AMERICAN'S CEASE-FIRE STATION:

- ★ Low Maintenance
- ★ Ships Fully Assembled
- ★ Ties down to prevent theft

Your smoker station is fully assembled and ready to use. We recommend additional weight be added to the bottom to avoid tipping over in adverse weather conditions.

Getting Started:



When you first use your station, you may experience a bit of smoke escaping from the top. This is normal as it takes the disposal of a few cigarettes to use up all of the oxygen in the container. Under heavy use conditions, the unit should be cleaned regularly to prevent excessive tar build-up.

TO ADD ADDITIONAL WEIGHT:

1. Unscrew and remove the black knob near bottom of the unit. Turn top slightly and lift the top off.
2. Fill the liner pail to half full with sand, or place rocks around the perimeter of the base.
3. Once weight has been added, replace the top section, align the front slot and slide down. Turn top slightly to the left so hole on top aligns with the threaded insert of the bottom. Screw in knob to secure top and bottom together.

TO SECURE YOUR UNIT IN PLACE:

Using a lock or chain, use the holes found at the base of the unit (one on each side) to secure your unit to an unmovable object. Locking the station will not interfere with opening your unit for cleaning.



This smoker station is designed to limit the flow of oxygen, thereby eliminating the chance of fire. To function properly, this unit must be **SECURELY CLOSED AT ALL TIMES.**

